

RA-4: Non Standard Processing Applications

Kis DKS Processing Machines						
Processing Stage	Champion Product	Processing Time (Sec)	Working Temperature (°C)	Replenishment Rate mls/sqm	DKS Replenisher Pump Ratio mls Concentrate / Water	Preparation of Working Tank Solution (1L)
Developer P1	Primaprint SP LORR Developer / Replenisher	20 / 27	40± 0.3 °C	108	0.15 / 0.85	1) 860mls Water
	Product Code: 140150					2) 80mls Developer Concentrate
	RA4 Print Starter - 140411					3) 60mls RA4 Starter
Bleach-Fix P2	Naturecare SNR Bleach-Fix Replenisher	20 / 27	40± 0.3 °C	108	0.275 / 0.725	1) 725mls Water
	Product Code: 140561					2) 275mls Bleach-Fix Concentrate
Stabiliser Rinse P3	Mydoprint Rinse / Stabiliser	20 / 27	40± 0.3 °C	350	0.01 / 0.990	1) 990mls Water
	Product Code: 141006					2) 10mls Stabiliser Concentrate

Important Note

1. The replenisher concentrate is used straight from the bottle. No dilution is required.
2. Place the bottle in the door of the machine, remove the cap and make a small hole in the seal.
3. Slide the take up tube down into the bottle, ensure that the tube is not pushed completely down as this will prevent liquid from being sucked up by the machine.
4. Close door.

Short Development Time Applications						
Processing Stage	Champion Product	Processing Time (Sec)	Working Temperature (°C)	Replenishment Rate mls/sqm	Replenisher Mix 10L	Preparation of Working Tank Solution (1L)*
Developer P1	Primaprint SP LORR Developer / Replenisher	27 33	39± 1 °C	90	1) 8.95L Water 2) 1x Bottle of Concentrate	1) 860mls Water
	Product Code: 140150					2) 80mls Developer Concentrate
	RA4 Print Starter - 140411					3) 60mls RA4 Starter
Bleach-Fix P2	Naturecare SNR Bleach-Fix Replenisher	27 - 33	39± 1 °C	70	1) 6L Water 2) 1x Bottle of Concentrate	1) 725mls Water
	Product Code: 140561					2) 275mls Bleach-Fix Concentrate
Stabiliser Rinse P3	Mydoprint Rinse / Stabiliser	27 - 33	39± 1 °C	250-350	1) 9.995L Water 2) 50mls of Concentrate	1) 990mls Water
	Product Code: 141006					2) 10mls Stabiliser Concentrate

Note

*Mixes can be used to start-up Konica R1 / R2 and Cartridge /Tablet machines, Agfa Dlab 1,2 & 3 printers and Kis DKS 3 machines.

Safe Use of Processing Chemicals: Please consult Champion SDS's for information relating to the safe use of products

WARRANTY: Seller, Champion Photochemistry, expressly disclaims any and all warranties, express or implied, including any warranties of merchantability or fitness. Seller's sole obligation for defect is to replace the defective product. In no event shall seller have any liability for incidental or consequential damages.



Manufactured in Malaysia for
CHAMPION PHOTOCHEMISTRY SDN BHD
Lot 28-B, Mukim Batu Industrial Area, 6½ Miles Jalan Kepong
52000 Kuala Lumpur, Malaysia
Telephone: (603) 6257-2600 Fax (603) 6257-2622
Website: www.championphotochemistry.com